
NISSAN NAVARA NP300 D23 ANY TIME DIFF LOCK KIT

INSTRUCTIONS

WARNING: For off road use only. Never engage your diff lock while accelerating, as this could damage the locking mechanism. Improper use of your diff lock or abuse can damage your vehicle.

1. Open and remove the glove box
2. Locate the diff lock control module (DLCM)
3. Remove the plug from the DLCM
4. Plug the Anytime Diff Lock Kit into the DLCM and the factory plug removed from the DLCM
5. Remove the centre console to gain access to the switches. See here for help: https://youtu.be/DKEb2H8PRaI
6. The factory diff lock switch needs to remain connected for this kit to function. Remove the factory switch from the facia panel and secure behind the dash.
7. Install and connect the supplied diff lock switch into facia panel.
8. Optional – Connect the green wire from the diff lock switch to +12V dash light Illumination.
9. Reinstall centre console and glove box.







QUESTIONS & TECHNICAL ASSISTANCE

If you have any questions or require technical assistance our staff are available to assist.
Phone: (02) 9191 7348
Monday to Saturday 9 AM to 5 PM
Email: sales@perceptionlighting.com.au